

# SafeTemp™

## Retail Food Display Temperature Monitoring System

### SafeTemp™ activates when temperature is NOT correct!


A proprietary system of temperature monitors for temperature controlled retail display cases that fits into shelf channels. Designed to complement centralized electronic temperature management systems without power or maintenance.

This digital system alerts staff to localized (within cold/freezer and hot case) temperature excursions immediately allowing for rapid remedy.



### safetemp™CC

Chill Checker lights up when temperature is too warm



### safetemp™FC

Freeze Checker lights up when temperature is too warm



Shelf size (small)



Wall size (large)

### safetemp™HZ

Hotzone lights up when temperature is too cool



### Perfect for:

- Refrigerated & Hot Food Display Cabinets
- Freezer Cases
- Multideck and Wall cabinets
- Glass Front Uprights

### Features:

- Real Time Air and Food Temperature
- Easy to Read Digital Alert
- Fits Standard Cases
- Black to an Alert Temperature Point
- Reverses with Correct Temperature
- Accurate +2°C
- Custom sizes, shapes, and temperatures available

### Alerts Staff to:

- Blocked Air Grills
- Disrupted Cold Air Curtain
- Overfilled Cabinets
- Icing
- Low temperature (Hot Foods)

# SafeTemp™

## SPECIFICATIONS

### safetemp™CC

Chillchecker Lights up When Temperature is Too Warm

Code	Description	Temp	Size	Activation Color	Supplied
3087 ADP50	Chiller Indicator	39°F	1.25" x 1.25"	Red	Pack of 50
3088 ADP50	Chiller Indicator	41°F	1.25" x 1.25"	Red	Pack of 50
3089 ADP50	Chiller Indicator	46°F	1.25" x 1.25"	Red	Pack of 50
3090 ADP1	Lg Chiller Indicator	39°F	9.50" x 6.80"	Red	Single
3091 ADP1	Lg Chiller Indicator	41°F	9.50" x 6.80"	Red	Single
3092 ADP1	Lg Chiller Indicator	46°F	9.50" x 6.80"	Red	Single

**Instructions for use:**

1. Place a Chiller/Freezer Monitor at regular intervals along shelf edge strip, or other positions.
2. Check regularly. If Chiller/Freezer Monitor remains black, temperature is still correctly below activation point.
3. If Chiller/Freezer Monitor turns red, it is a warning that the storage temperature is too warm.

**Bracketed Indicators for Deli Counters and Chiller Cabinets**

Code	Description	Temp	Size	Activation Color	Supplied
3087 PKG50	Red L Bracket	39°F	1.25" x 1.25"	Red	Pack of 50
3088 PKG50	White L Bracket	41°F	1.25" x 1.25"	Red	Pack of 50

**Instructions for use:**

1. Place bracket within deli/meat cabinet facing inwards for instant visibility by counter staff.
2. Check regularly. If Chiller/Freezer Monitor remains black, temperature is still correctly below activation point.
3. If Chiller/Freezer Monitor turns red, it is a warning that the storage temperature is too warm.



### safetemp™FC

Freeze Checker – Alerts to Warm Temperature

Code	Description	Temp	Size	Activation Color	Supplied
3093 ADP50	Freezer Indicator	0°F	1.25" x 1.25"	Red	Pack of 50
3094 ADP1	Lg Freezer Indicator	0°F	9.50" x 6.80"	Red	Single

**Instructions for use:**

1. Place a Chiller/Freezer Monitor at regular intervals along shelf edge strip, or other positions.
2. Check regularly. If Chiller/Freezer Monitor remains black, temperature is still correctly below activation point.
3. If Chiller/Freezer Monitor shows "F," it is a warning that the storage temperature is too warm.

**HOW TO READ**



### safetemp™HC

Hotzone – Lights Up when Temperature Is Too Cool

Code	Description	Temp	Size	Activation Color	Supplied
3095 PKG50	Hotzone temp. monitor on Bracket	145°F	Monitor: 1.25" x 1.25" Bracket: 3"	Blue	Pack of 50
3095 ADP50	Hotzone temp.	145°F	1.25" x 1.25"	Blue	Pack of 50

**Instructions for use:**

1. Place the hotzone bracket onto the middle of an upper shelf within the hot food cabinet.
2. If the indicator remains black, the temperature is correctly above 145°F.
3. If the indicator reveals the number 145, the temperature has fallen below 145°F.



**HOW TO READ**

