

# Tempasure

## Quality Assurance for Products Sensitive to Low Temperature


### The Way It Works



Pull safety TAB to activate sensor. Attach with self-adhesive backing.



A clear window indicates the unit has not been exposed to critical low temperature.



Indicator clearly shows a red window when product has experienced temperatures below indicated rating.

### Highlights:

- **Easy To Use and Read**  
**Self-Adhesive**  
**Pull Tab to Activate**
- **After Activation, Window Will Show Red at Temperature Below Indicated Rating**
- **Mechanical and Irreversible**
- **Sturdy and Small - Great For Storage And Transit**
- **Temperature Range:**  
**-20°C to 10°C (-4°F to 50°F)**
- **Accurate to ±2°C (±3.6°F)**



### Specifications

#	Description	Size	Critical Temp
D-20C	Descending	1.4"L x 0.7"W x 0.2"H	-20°C
D-10C	Descending	1.4"L x 0.7"W x 0.2"H	-10°C
D-5C	Descending	1.4"L x 0.7"W x 0.2"H	-5°C
D0C	Descending	1.4"L x 0.7"W x 0.2"H	0°C
D+2C	Descending	1.4"L x 0.7"W x 0.2"H	+2°C
D+5C	Descending	1.4"L x 0.7"W x 0.2"H	+5°C
D+10C	Descending	1.4"L x 0.7"W x 0.2"H	+10°C

### How to Use

1. Allow sensor to stabilize at product temperature
2. Pull safety tab to activate sensor
3. Remove release liner and attach with self adhesive backing
4. A clear window indicates that the unit has not been exposed to critical low temperature
5. Indicator window shows red when exposed to a low temperature that is at or below its rating